

DTSX - DTSXY AO DEFLECTORS 1-axis/2-axis

Product Overview

These high-resolution deflectors operate with Te02 shear mode and hence offers a large scan angle, resolution up to 400 dots and, large aperture up to 7.5 mm. Associated to the appropriate RF driver, this device will provide high precision and accuracy which is required for most application such as optical tweezers, biomedical diagnostics and many others. They are available as 1-axis or 2-axis deflectors.








2-axis compact

Features

- Large active aperture
- Large scan angle
- High resolution
- High diffraction efficiency

| | | DTSX (1-axis) | DTSXY (2-axis) | |
|--|------------|---|---|--|
| Material-Acoustic mode-Velocity | | TeO2 [S] - 650 m/s | | |
| Optical Wavelength range (AR coated) (λ) | | Designed for a single wavelength, on request in 405-1550 nm | | |
| Optical Transmission | | >95 % per axis | | |
| Input / Output Polarization | | Linear / Polarization flip 90° per axis | | |
| Active aperture | 250 series | 4.5 x 4.5 mm² | | |
| | 400 series | 7.5 x 7.5 mm ² | | |
| Frequency range (ΔF) | | 50 MHz @ 532 nm | | |
| Scan angle | | 49 mrd @ 1064 nm | 49 mrd² @ 1064 nm | |
| Static Extinction Ratio | | >33 dB | | |
| Rise time (Tr) | | 1μs/mm | | |
| Access time (Ta) | | 1.5μs/mm | | |
| Diffraction Efficiency (η) | | >70% | > 40%, nom 50% | |
| Resolution (N) | 250 series | 300 @ 633 nm | 300x300 @ 633 nm | |
| | 400 series | 500 @ 633 nm | 500x500 @633 nm | |
| Max Optical power density | 532 nm | 5 W/mm² | | |
| | 1064 nm | 10W/mm² | | |
| Input impedance | | | 50Ω | |
| V.S.W.R. | | < | <.2:1 | |
| RF Power (P) | 532 nm | 1 W | | |
| | 1064 nm | 2 W | | |
| Weight | | аррг | approx 60 g | |
| Packaging | | IN PRO 163 | IN PRO 161 (Standard) IN PRO 180 (Compact) | |
| Operating Temperature (non condensing) | | + 10 °C to + 40 | + 10 ℃ to + 40 ℃ non-condensing | |
| Storage Temperature (non condensing) | | -20 °C to +50 °C | -20 ℃ to +50 ℃ non-condensing | |
| RoHS Compliance | | Yes | | |





$$N = T_a \times \Delta f$$

$$N = \frac{\Delta \theta}{\delta \theta}$$


$$T_a = \frac{\phi}{V}$$

ΔF: RF frequency range

λ: Wavelength of laser beam

Δθ: Scan Angle **V**: Acoustic velocity

N: number of resolvable points



Angular Sketch (Top view): DTSXxx and DTSXYxx devices are « colinear »



AA OPTO-ELECTRONIC 18, rue Nicolas Appert 91898 ORSAY FRANCE Tel: +33 (0)1 76 91 50 12 Fax: +33 (0)1 76 91 50 31 www.aaoptoelectronic.com

AA Sa reserves the right to make changes to the products or information herein without notice. No liability is assumed as a result of their use or application.

